




Check chemical levels in containers




2 Flip ON/OFF switch to ON position



Wait 20 minutes for temperature gauge to read 150°F/66°C




Prescrap wares and load into rack



5 Load rack into dishwasher



Close door, press and hold START button for 1 second and green in-cycle light will indicate the cycle has begun



Final rinse temperature should be a minimum of 180°F/82°C during final rinse.



Wash cycle is extended if the final rinse temperature is not maintained at 180°F/82°C.



The cycle is completed when the green light is no longer lit.

You may now remove your clean wares.

Exercise caution handling wares as they may be hot.